











### 4816-315-S LADDER BACK CHAIR

**WARNING:** To avoid alignment issue, please don't tighten the screws unless all leg are adjusted at the same level.

HARDWARE LIST			QTY
A	Short Bolt Ø1/4" x 20 x 1-1/2"		2 PCS
B	Medium Bolt Ø1/4" x 20 x 2-3/8"		4 PCS
C	Long Bolt Ø1/4" x 20 x 3-1/8"		4 PCS
D	Spring Washer Ø1/4" x Ø1/2" x 1/16"		10 PCS
E	Flat Washer		10 PCS
F	Allen Key 1/8"		1 PC

PART LIST			QTY
1	CHAIR BACK		1 PC
2	SEAT		1 PC
3	FRONT LEG		2 PCS




ASSEMBLY COMPLETED

**Hardware Pack Location(s):**

# Assembly Instruction

\*\*\*Caution: Please read all instructions carefully before starting the assembly process. These parts are cumbersome and heavy. Therefore, two people are recommended in order to prevent personal injury and ensure the parts are not damaged during the assembly.


## STEP 1



Attach the seat frame to the chair back.

Note: Do not tighten all screws & bolts until the chair is fully assembly .

## STEP 2



Attach front leg to the seat frame.

Note: Do not tighten all screws & bolts until the chair is fully assembly .

 **WARNING: To avoid serious personal injury:**

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.