


 WARNING: To avoid serious personal injury:

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.

ASSEMBLY INSTRUCTIONS:

1. CAREFULLY UNPACK AND PLACE ALL LAMP PARTS ON A FLAT SURFACE AND LINE THEM UP AS PER SKETCH.
2. INSERT HARP (B) INTO SADDLE AT THE TOP OF BODY (A).
3. PLACE SHADE (C) ONTO HARP (B) AND SECURE WITH FINIAL (D).
4. INSTALL THE LAMP BULB (E)(NOT INCLUDED) AND INSERT THE POLARIZED PLUG INTO AN OUTLET, TURN ON THE SWITCH AND ENJOY YOUR LAMP.

**USE A 100W (MAXIMUM) IN CANDESCENT A TYPE BULB
(NOT INCLUDED)**



IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK, THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY AND EASILY INSERTED. DO NOT ATTEMPT TO ALTER THIS PLUG.

ATTENTION:

POUR PRÉVENIR LES CHOCS ÉLECTRIQUES NE PAS UTILISER CETTE FICHE POLARISÉE AVEC UN PROLONGATEUR, UNE PRISE DE COURANT OU UNE AUTRE SORTIE DE COURANT, SAUF SI LES LAMES PEUVENT ÊTRE INSÉRÉES À FOND SANS EN LAISSER AUCUNE PARTIE À DÉCOUVERT.

✂ **PLEASE INFORM YOUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE.**

✂ **SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.**