WARNING: To avoid serious personal injury:

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small
 parts and hardware that may present a choking hazard to small children.
 Bob's furniture should be assembled only by responsible adults and children
 should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as
 prescribed in these instructions to anchor furniture to wall. Proper use of the
 wall mounting hardware can significantly reduce the potential for furniture
 tip-over and crushing injuries.

ASSEMBLY INSTRUCTIONS:

- 1. Carefully unpack and place all lamp parts on a flat surface.
- 2. Connect the pole(D) onto base(E) with screw(F) by wrench (G).
- 3. Connect male end and female end of quick connector(C) together.
- 4. Connect the shade(A) onto the pole (D) with screw(B) by wrench (K).
- 5. Secure the glass fiber tube(H) into the pole (D) with screw(I) by screw driver (J).
- 6. Connect the power cord from the pole (D) to the power cord of switch(L).
- 7. Connect the power cord of switch(L) to the power cord of adapter(M).

CAUTION: THE POWER CORD OF THE ADAPTER(M) CAN NOT CONNECT WITH THE POWER CORD FROM THE POLE(D) DIRECTLY!

8. Plug into outlet, turn on the switch and enjoy your new lamp.

USE A 30W (MAXIMUM) LED (INCLUDED)

- **** PLEASE INFORM YOUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE.**
- **** SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.**

