



# ASSEMBLY INSTRUCTIONS



 **WARNING:** To avoid serious personal injury:

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.

P.1	RTA-3800SU	P.1
-----	------------	-----



- Please read carefully the assembly instructions before the installation.













- Do not discard this manual or any of the packaging material until the unit has been completely assembled.











- Might require two people.






MAIN PARTS LIST			
1 x1	Back tabletop	2 x1	Front tabletop
3 x2	Metal leg	4 x1	Back structure
5 x1	Front structure	6 x1	Central structure
7 x2	Back lift structure	8 x2	Front lift structure
9 x1	Headphone hanger	10 x1	Cup holder

LIST OF HARDWARE, SCREWS AND FITTINGS			
PART	QTY	ITEM	
A	12	M6x38	
B	4	M6x32	
C	2	M6x25	
D	6	M4x12	
E	2	Non-locking caster	
F	2	Locking caster	


PART	QTY	ITEM	
G1	4	Plastic cover	
G2	4	Screw knob	
H	1	Allen wrench	
I	1	Cone wrench (Spanner)	



P.3		P.3
BEFORE YOU START THE ASSEMBLY, PLEASE READ THE FOLLOWING TIPS AND WARNINGS.		
<ul style="list-style-type: none"> <li>Do not discard this manual or any of the packaging material until the unit is completely assembled.</li> <li>Please read the assembly instructions thoroughly and follow step by step.</li> </ul>		
<ul style="list-style-type: none"> <li>The assembly might require of 2 persons for certain steps. Before you start the instalation, make sure there is someone else nearby to help you.</li> </ul>		
<ul style="list-style-type: none"> <li>Make sure you understand which hardware will be used on each step. Using the wrong size of screw, bolt or pin might strip the threads or cause damage to the part in which it is being used.</li> </ul>		
<ul style="list-style-type: none"> <li>To avoid misalignments, always leave the screws loosely and do not tighten them until all the pieces are positioned correctly.</li> <li>Do not overtighten or force the screws as they might break, strip, damage the threads of the holes, or get stuck inside the parts.</li> </ul>		
<ul style="list-style-type: none"> <li>If the hole seems to small for the screw, make sure you are using the correct size of screw and/or that you are installing it in the correct hole.</li> </ul>		
<ul style="list-style-type: none"> <li>Sometimes on the wood panels the laminate or material might be covering the hole partially or entirely, if there is no visible hole or if it looks too small, pass and press the tip of your finger over the area to feel its indentation, and carefully pierce the laminate to uncover the hole underneath.</li> </ul>		
<ul style="list-style-type: none"> <li>After the item is assembled, you can use rubbing alcohol to erase or remove the visible part numbers printed or labeled on the pieces.</li> </ul>		
<ul style="list-style-type: none"> <li>Please be kind to our planet, when done with the assembly, recycle any of the packaging materials that is accepted by your city or recycling service.</li> </ul>	 <p>Thank you!</p>	

ASSEMBLY STEPS


STEP 1		
Hardware:		
E	 Non locking	2 Pcs
F	 Locking	2 Pcs
G1	 Covers	4 Pcs
G2	 Screw knob	4 Pcs
I		

First install the non-locking casters **E** at the back of the legs **3**, and the locking casters **F** at the front using the cone wrench (spanner) as shown. Then attach the plastic covers **G1** and screw knobs **G2** to the top of the legs **3**, making sure the knob faces towards the back as shown.



STEP 2		
Hardware:		
A	 M6x38	4 Pcs
H		

Assemble the central structure **6** in between the legs **3** using screws **A** as shown.



STEP 3

Hardware:

A




4  
Pcs

H



Assemble the back structure **4** to the back lift structures **7** using screws **A** as shown.



STEP 4

Hardware:

A




4  
Pcs

H




Assemble the front structure **5** to the front lift structures **8** using screws **A**, making sure the holes on **5** face UP as shown.



STEP 5



First make sure the screw knobs **G2** are loose, then with the help of another person, insert the front lift structures **8** thru the covers **G1** and into the legs **3**. **DO NOT TIGHTEN** the screw knobs yet.




STEP 6

Hardware:

C		2 Pcs
D		2 Pcs
H		

Assemble the front tabletop **2** to the frame using:

- Screws **C** to secure it to the structure **5** from underneath,
- Screws **D** to secure it to the lift structures **8** from underneath.



NOTE: The front of the tabletop has the pre-drilled holes near the corner on both sides.


**C** for the front,  
**D** for the back.

## STEP 7



First make sure the screw knobs **G2** are loose, then with the help of another person, insert the back lift structures **7** thru the covers **G1** and into the legs **3**. **DO NOT TIGHTEN** the screw knobs yet.

UNIT IS SHOWN FROM BEHIND WITH ITS FRONT FACING TO THE RIGHT.




## STEP 8

## Hardware:

**B**  4 Pcs  
M6x32

**H** 



Assemble the back tabletop **1** to the back lift structures **7** using screws **B** as shown








STEP 9

Hardware:

D	 M4x12	4 Pcs
H		


Assemble the headphone hanger **9** and the cup holder **10** to the front tabletop **2** on the sides of your preference using screws **D** from underneath as shown. Proceed to set the heights of the tabletops according to your preference, and tighten the screw knobs.




## ALL DONE!

Give yourself a nice pat on the back. You did a great job!



**AFTER THE ASSEMBLY IS DONE, PLEASE READ CAREFULLY THE FOLLOWING CARE AND MAINTENANCE WARNINGS:**

**WEIGHT LIMITS**



- Do not exceed the indicated weight limits.
- Do not expose the surfaces to direct sunlight or to extreme environmental conditions.
- Clean the surfaces preferable with a clean cloth damped in a solution of mild soap and water, then dry with a clean towel.
- Do not use solvents or abrasive materials to clean the unit.
- If you decide to use a cleaning agent, test first on an area hidden from view such as underneath the tabletop.
- Do not sit on the unit or lean against it.
- Always keep the unit with the front casters locked, and do not allow small children to play under or over the unit, move it, or use it as moving vehicle to avoid the risk of objects falling from it and hurting them.
- Before moving the unit, make sure to unlock the front casters and hold, secure or remove any object that might fall off.
- When transporting the unit to places far away, protect and secure the unit to avoid damage in transit.
- Shall any part of the unit become defective during the warranty period, replacement parts might be available to you at no charge. Please refer to the last pages on this manual.
- The warranty does not extend to regular wear and tear, nor the manufacturer assumes liability for damages or consequences due to accidents, incorrect assembly, negligence, improper use, modifications, or not heeding the above warnings.