




- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children.
  Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.

## ASSEMBLY INSTRUCTION







This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage. Attach Side Panel (A) to Metal Frame (B) by Bolt (F) and Allen Wrench (M) as shown.




Attach Railing (C) to Metal Frame (B) by Bolt (F) and Allen Wrench (M) as shown.




Attach Handle (D) to Side Panel (A) by Bolt (G) and Allen Wrench (M), then attach Caster (I) and Caster With Brake (H) to Side Panel (A) by Open Wrench (N) as shown.



Attach Suction Cup (L) to Metal Frame (B), then attach Small End Cap (J) to Side Panel (A) as shown.





## **Cleaning & Care**

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.