






ASSEMBLY INSTRUCTION






DESCRIPTION: DRAWER DRESSER&LANDSCAPE MIRROR

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small Hardware which may have come loose inside the carton during shipment. Identity and count all hardware and compare with the hardware list below.


PARTS LIST:

NO.	Description	Sketch	Quantity
A	Dresser		1PC
B	Foot		4PCS
C	Center legs		1PC
D	Mirror		1PC
E	Mirror Support		2PCS


HARDWARE LIST:

NO.	Description	Sketch	Quantity
1	Allen bolt 1/4 "X35mm		8PCS
2	Flat washer 1/4 "X19x1.5mm		8PCS
3	Spring washer 1/4 "		8PCS
4	Allen key 4mm		1PC
5	Anti tipping kits		1SET


STEP 1



STEP 2




STEP 4



D

A



STEP 3

MADE IN VIETNAM



WARNING: To avoid serious personal injury:

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.