BOB'S FURNITURE

ASSEMBLY INSTRUCTION


DOUBLE TRESTLE DINING TABLE


WARNING: To avoid alignment issue, please don't tighten the screws unless all legs are adjusted at the same level.


HAI	RDWARE LIST/ LISTE DE QU	JINCAILLERIE	QTY'/ QTÉ
1	Long Bolt Ø1/4"x 64mm		8 PCS
2	Spring washer Ø5/16"x 12mm		12 PCS
3	Flat washer Ø5/16"x 19mm		12 PCS
4	Allen Key 58 x 23 x 4 mm		1 PC
5	Short Bolt Ø1/4"x 45 mm		4 PCS
6	Spring washer Ø5/16"x 12mm (Black color)		8 PCS
7	Small Flat washer Ø5/16"x 14mm (Black color)		8 PCS
8	Long Bolt Ø5/16"x 64 mm (Black color)		8 PCS


PART LIST/LISTE DE PIÈCES			QTY'/ QTÉ
Α	TABLE TOP		1 PC
В	TABLE LEAF		2 PCS
С	LEGS		2 PCS
D	CONNECTOR PANEL		2 PCS
E	BOTTOM RAIL		2 PCS
F	САР		4 PCS

STEP 1












STEP 5





STEP 7 B RELOCK





MARNING: To avoid serious personal injury:

- · Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- · Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- · Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.