
ASSEMBLY INSTRUCTIONS




LADDER BACK PUB CHAIR / CHAISE


WARNING: To avoid alignment issue, please don't tighten the screws unless all legs are adjusted at the same level.

	WARMING. To avoid alignment issue, please don't lighter				
HARDWARE LIST/ LISTE DE QUINCAILLERIE					
1	Short Bolt φ1/4" x38 mm	The latter transmitted	3 pcs		
2	Long Bolt φ1/4" x85 mm		4 pcs		
3	Hex-Nut φ5/16"		4 pcs		
	Spring Washer φ5/16" x12 mm	8	11 pcs		
5	Flat Washer φ5/16" x19 mm	0	11 pcs		
6	Allen Key 58 x 23 x 4 mm		1 pc		
7	Wrench 12 x 75 mm		1 pc		
8	Screw φ8 x 50 mm	{) 	6 pcs		



PART LIST/LISTE DE PIÈCES			QTY'/ QTÉ
Α	CHAIR BACK	Fri Time	1 PC
	DOSSIER DE CHAISE		
В	SEAT		1 PC
	FRONT LEG (LEFT - RIGHT)		2 PCS
) SIDE STRETCHER		2 PCS
D	L .		
Е	FRONT STRETCHER		1 PC







WARNING: To avoid serious personal injury:

- · Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- · Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- · Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.