









WARNING: To avoid alignment issue, please don't tighten the screws unless all legs are adjusted at the same level.




HARDWARE LIST/ LISTE DE QUINCAILLERIE

1	Short Bolt $\phi 1/4"$ x42 mm		8 pcs 8 pièces
	Boulon $\phi 1/4"$ x42 mm		
2	Long Bolt $\phi 1/4"$ x75 mm		2 pcs 2 pièces
	Boulon $\phi 1/4"$ x75 mm		
3	Spring Washer $\phi 5/16"$ x12 mm		10 pcs 10 pièces
	Rondelle de ressort $\phi 5/16"$ x12 mm		
4	Flat Washer $\phi 5/16"$ x19 mm		8 pcs 8 pièces
	Rondelle plate $\phi 5/16"$ x19 mm		
5	Small Washer $\phi 1/4"$ x12 mm		2 pcs 2 pièces
	Rondelle plate $\phi 1/4"$ x12 mm		
6	Allen Key 58 x 23 x 4 mm		1 pc 1 pièce
	Clé Allen 58 x 23 x 4 mm		
7	Wood cap $\phi 13.5$ x 8mm		2 pcs 2 pièces




ASSEMBLY COMPLETED


PART LIST/LISTE DE PIÈCES

PART LIST/LISTE DE PIÈCES			QTY'/ QTÉ
A	SEAT		1 PC 1 PIÈCE
	SIEGE		
B	LEGS		2 PCS 2 PIÈCES
	PIEDS		
C	BOTTOM RAIL		1 PC 1 PIÈCE
	BARREAU DU BAS		

STEP 1 ÉTAPE 1



STEP 2
ÉTAPE 2





WARNING: To avoid serious personal injury:

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to walls. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.