



ASSEMBLY INSTRUCTION

30" Vanity



SCAN ME

Assembly Video



60 minutes


WARNING: To avoid serious personal injury:

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.

Tools Required



(Included)




(Not Included)


















(Not Included)

Part list - 30" Vanity



Identifying the hardware-Identify the hardware using the illustrations below

A  Ø8*30mm Wood Dowel	B  M6*45mm Bolt	C  Ø6*16mm Washer
D  Hinge	E  Drawer Slide	F  3.5*15mm Screw
G  Knob	H  M4*25mm Bolt	I  Leveler
J  4*50mm Screw	K  Hex Wrench	L  Ø6*20mm Wood Dowel
M  3.5*12mm Screw	N  4*25mm Screw	O  4*40mm Anchor

Step 01

Identify the back of slide



Ball Bearing slides Soft Close Mechanism




The front of slide




The back of slide

Step 02


E  02

Slide the track out



Step 03

Ensure the soft-close damper trigger has been returned to the starting point.






X2

Step 04

Align the outer member to the 2 pilot holes on the Side Panel(2), put 2*Screws(M) in. Refer DIM.C

M  **02**
3.5*12mm Screw

 **01**





Step 05

Align the outer member to the 2 pilot holes on the Side Panel(3), put 2*Screws(M) in. Refer DIM.D


M 3.5*12mm Screw **02**


01



Step 06

A  **06**
Ø8*30mm Wood Dowel

 **01**
(Not Included)





Step 07

B  **06**
M6*45mm Bolt

C  **06**
Ø6*16mm Washer


K  **01**
Hex Wrench

I  **02**
Leveler



Note: Do not tighten bolts firmly at this time

Step 08





B  **06**
M6*45mm Bolt

C  **06**
Ø6*16mm Washer


K  **01**
Hex Wrench

I  **02**
Leveler



Note: Tighten all bolts at this time

Step 09




D  **02**
Hinge


F  **04**
3.5*15mm Screw

G  **01**
Knob


H  **01**
4*25mm Screw

 **01**


Step 10




D		02
F		04
G		01
H		01
		01



Step 11






F		08
		01



Align slotted holes in Hinge Mounting plate on 2 doors with pilot holes on Left End Panel(2) and Right End Panel(3). Attach 2 doors using Screw F - 8 places. Screw F should be centered vertically in the slotted holes.
Note: Final adjustments may be required. To adjust up or down, loosen Screw F, Adjust as necessary and re-tighten Screw F.

Step 12






If any hinge requires slight adjustment out, loosen Bolt II and adjust out as necessary.




To adjust the Left Hand Doors: Adjust door to Right by turning Bolt III clockwise. Adjust door to Left by turning Bolt III counterclockwise.

To adjust the Right Hand Doors: Adjust door to Left by turning screw III clockwise. Adjust door to Right by turning screw III counterclockwise.



Once all adjustments are made and doors are aligned, install set screw F in the last 2 holes in the mounting plate, on 2 doors, 8 places.

Step 13

N		08
4*25mm Screw		
L		08
Ø6*20mm Wood Dowel		
		01




Step 14





M 3.5*12mm Screw **02**

01
(Not Included)




Align inner member of the Drawer Track set with pilot holes in the Drawer Box Side 9.
Attach the inner member using screw M

Step 15



M 3.5*12mm Screw **02**


01
(Not Included)



Align inner member of the Drawer Track set with pilot holes in the Drawer Box Side 10.
Attach the inner member using screw M


Step 16

Holes in the drawer box fronts are slightly oversized to allow for minor adjustments. Adjust drawer fronts as necessary to achieve equal spacing.



N  **06**
4*25mm Screw


 **01**
(Not Included)




Step 17


G  **02**
Knob

H  **02**
4*25mm Screw

 **01**



Step 18



Insert the inner member into the outer member and push the drawer all of the way in. Do not use an excessive amount of force when inserting the drawer.



Note: If the drawer can not be closed with ease, please remove the drawer and then try to insert it again. If the drawer still cannot be closed successfully, go back to the beginning and double check that your installation has followed all steps accurately

Step 19

Drawer adjustments

Adjust Screws(M) in the Inner Member up or down, adjust Screws(M) in the Outer Member in or out, loosen Screw M, adjust as necessary to have equal spacing around the edges of drawer faces. Re-tighten

Screw M after the adjustment is done.





Step 20

Secure each inner member by 2 Wood Screws(M)
Refer Dim.G

M 04
3.5*12mm Screw

01




Step 21

See illustrations below to release Inner member for outer member

M 3.5*12mm Screw 04

01



Fix each outer member by 2 Wood Screws(M).Refer Dim H.

Step 22

J 4*50mm Screw 02

O 4*40mm Anchor 02

01

- . For best results, we suggest securing your Vanity to a stud in at least two locations.
- . Mark the location of the Studs in the wall on the stretcher rail.
- . Drill a 1/16" thru hole in the center of the Stretcher Rail at the location of the studs in the wall.
- . Secure the Vanity to the wall using screws (J) make sure the screws align with the Stud in the wall.
- . If hole locations do not align with stud in wall, install the EZ Anchor(O) in to drywall and then screwing the EZ Anchor in to the drywall.

